



Contents

| | |
|---|-------------|
| The Author | VII |
| Preface to the Third Edition | IX |
| Preface to the Second Edition | XI |
| Preface to the First Edition | XIII |
| 1 Introduction to Scientific Processing | 1 |
| 1.1 The Evolution and Progress of Injection Molding | 1 |
| 1.2 The Molding Process | 2 |
| 1.3 The Three Types of Consistencies Required in Injection Molding | 3 |
| 1.4 Scientific Processing | 6 |
| 1.5 The Five Critical Factors of Molding | 9 |
| 1.5.1 Part Design | 9 |
| 1.5.2 Material Selection | 10 |
| 1.5.3 Mold Design and Construction | 10 |
| 1.5.4 Machine Selection | 11 |
| 1.5.5 Molding Process | 11 |
| 1.6 Concurrent Engineering | 12 |
| 1.7 Variation | 12 |
| 1.8 The Molding Parameters and a Recommended Process Development Procedure | 14 |

| | | |
|----------|---|-----------|
| 2 | Properties of Polymers and Plastics That Influence Injection Molding | 17 |
| 2.1 | Polymers | 17 |
| 2.2 | Molecular Weight and Molecular Weight Distribution | 19 |
| 2.3 | Polymer Morphology (Crystalline and Amorphous Polymers) | 21 |
| 2.4 | Role of Morphology in Injection Molding | 26 |
| 2.4.1 | Differences in Shrinkage between Amorphous and Crystalline Materials | 26 |
| 2.4.2 | Melt Processing Range | 27 |
| 2.4.3 | Mold Filling Speed | 28 |
| 2.4.4 | Mold Temperatures | 28 |
| 2.4.5 | Barrel Heat Profile | 29 |
| 2.4.6 | Screw Recovery Speeds | 29 |
| 2.4.7 | Nozzle Temperature Control | 30 |
| 2.4.8 | Cooling Times | 30 |
| 2.4.9 | Mechanical Properties | 30 |
| 2.4.10 | Optical Clarity | 30 |
| 2.5 | Exceptions of Morphology Rules to Polyolefins | 31 |
| 2.6 | Thermal Transitions in Polymers | 32 |
| 2.6.1 | Relationship between the Glass Transition Temperature and Post Mold Shrinkage | 38 |
| 2.6.2 | Importance of Mold Temperatures in Injection Molding | 41 |
| 2.7 | Shrinkage of Polymers in Injection Molding | 44 |
| 2.8 | The Plastic Pressure–Volume–Temperature (PVT) Relationship | 46 |
| 2.8.1 | Importance of Plastic Density in Injection Molding | 47 |
| 2.8.2 | Residence Time and Maximum Residence Time of a Plastic | 49 |
| 2.8.3 | Plastic Datasheets | 50 |
| 2.9 | References | 52 |
| 3 | Polymer Rheology | 55 |
| 3.1 | Viscosity | 55 |
| 3.2 | Newtonian and Non-Newtonian Materials | 57 |
| 3.3 | Viscosity in Polymer Melts | 58 |
| 3.4 | Effect of Temperature on Viscosity | 61 |
| 3.5 | Velocity and Shear Rate Profiles | 62 |

| | | |
|----------|---|-----------|
| 3.6 | Application to Injection Molding | 64 |
| 3.6.1 | Flow Imbalance in an 8-Cavity Mold | 64 |
| 3.6.2 | Racetrack Effect in a Part with Constant Thickness | 66 |
| 3.6.3 | Stress Build-Up in Molded Parts | 67 |
| 3.6.4 | Warpage Difference between Cavities | 67 |
| 3.7 | Solving Flow Imbalances Using Melt Rotation Techniques | 67 |
| 3.8 | Fountain Flow | 69 |
| 3.9 | Effect of Fountain Flow on Crystallinity, Molecular Orientation, and Fiber Orientation | 72 |
| 3.10 | Characterization of Polymer Viscosity | 73 |
| 3.11 | References | 75 |
| 4 | Plastic Drying | 77 |
| 4.1 | Problems in Melt Processing Related to the Presence of Moisture | 79 |
| 4.1.1 | Degradation of Plastic | 79 |
| 4.1.2 | Presence of Surface Defects | 80 |
| 4.2 | Hygroscopic Polymers | 83 |
| 4.3 | Drying of Plastics | 85 |
| 4.3.1 | Drying Temperatures and Times | 85 |
| 4.3.2 | Relative Humidity and Dew Point | 87 |
| 4.3.3 | Air Flow Rate | 88 |
| 4.4 | Equipment for Drying Plastics | 88 |
| 4.4.1 | Oven Dryers | 88 |
| 4.4.2 | Hot Air Dryers | 89 |
| 4.4.3 | Desiccant Dryers | 89 |
| 4.4.4 | Classifications Based on the Location of the Dryer | 89 |
| 4.5 | Determination of the Amount of Moisture | 90 |
| 4.5.1 | The Glass Slide Technique (TVI Test) | 90 |
| 4.5.2 | The Karl Fischer Titration Method | 91 |
| 4.5.3 | Electronic Moisture Analyzer | 91 |
| 4.5.4 | Measurement of the Dew Point | 92 |
| 4.6 | 'Overdrying' or Overexposure to Drying Temperatures | 93 |
| 4.7 | Cautions | 100 |
| 4.8 | Prevention of Overexposure to Longer Drying Times | 100 |
| 4.9 | Overdrying Controller | 100 |
| 4.10 | References | 102 |

| | | |
|----------|--|------------|
| 5 | Common Plastic Materials and Additives | 103 |
| 5.1 | Classification of Polymers | 103 |
| 5.2 | Commercially Important Plastics | 105 |
| 5.2.1 | Polyolefins | 105 |
| 5.2.2 | Polymers from Acrylonitrile, Butadiene, Styrene, and Acrylate | 106 |
| 5.2.3 | Polyamides (PA) | 107 |
| 5.2.4 | Polystyrenes (PS) | 108 |
| 5.2.5 | Acrylics | 109 |
| 5.2.6 | Polycarbonates (PC) | 109 |
| 5.2.7 | Polyesters | 109 |
| 5.2.8 | Polyvinyl Chloride (PVC) | 109 |
| 5.2.9 | Polyoxymethylene (POM or Acetal) | 110 |
| 5.2.10 | Fluoropolymers | 111 |
| 5.3 | Additives | 111 |
| 5.3.1 | Fillers | 111 |
| 5.3.2 | Plasticizers | 112 |
| 5.3.3 | Flame Retardants | 112 |
| 5.3.4 | Anti-Aging Additives, UV Stabilizers | 113 |
| 5.3.5 | Nucleating Agents | 113 |
| 5.3.6 | Lubricants | 113 |
| 5.3.7 | Processing Aids | 114 |
| 5.3.8 | Colorants | 114 |
| 5.3.9 | Blowing Agents | 114 |
| 5.3.10 | Other Polymers | 115 |
| 5.4 | Closing Remarks | 115 |
| 5.5 | Reference | 116 |
| 6 | Injection Molding and Molding Machines | 117 |
| 6.1 | The History of Injection Molding | 117 |
| 6.2 | Injection Molding Machines and Their Classifications | 118 |
| 6.3 | Machine Specifications | 120 |
| 6.3.1 | Clamp Force (Tonnage) | 121 |
| 6.3.2 | Shot Size | 121 |
| 6.3.3 | Screw Diameter and L/D Ratio | 121 |

| | | |
|----------|--|------------|
| 6.3.4 | Plasticating Capacity | 122 |
| 6.3.5 | Maximum Plastic Pressure | 122 |
| 6.4 | The Injection Molding Screw | 122 |
| 6.5 | Screw Designs | 125 |
| 6.6 | The Check Ring Assembly | 126 |
| 6.7 | Intensification Ratio (IR) | 126 |
| 6.8 | Obtaining Intensification Ratios | 128 |
| 6.9 | Selecting the Right Machine for the Mold | 129 |
| 6.9.1 | Physical Size of the Mold | 130 |
| 6.9.2 | Calculating the Required Machine Tonnage for a Mold | 132 |
| 6.9.3 | Percentage Shot Size Used and Number of Shots in the Barrel ... | 137 |
| 6.9.4 | Residence Time of the Material in the Barrel | 140 |
| 6.9.5 | Practical Methods to Find Percentage Shot Size, Shots in a Barrel, and Residence Time | 141 |
| 6.9.6 | Residence Time Distribution | 142 |
| 7 | Scientific Processing, Scientific Molding, and Molding Parameters..... | 143 |
| 7.1 | Introduction | 143 |
| 7.2 | What Scientific Molding and Scientific Processing Are Not! | 145 |
| 7.3 | Process Robustness | 145 |
| 7.4 | Process Consistency | 146 |
| 7.5 | The Injection Molding Cycle | 149 |
| 7.6 | The Injection, Pack, and Hold Phases of Injection Molding | 150 |
| 7.7 | Speed and Pressure | 153 |
| 7.8 | The 11 + 2 Plastic Injection Molding Machine Input Parameters | 154 |
| 7.8.1 | Barrel Temperatures | 155 |
| 7.8.2 | Mold Temperatures | 156 |
| 7.8.3 | Shot Size | 158 |
| 7.8.4 | Transfer Position | 158 |
| 7.8.5 | Injection Speed (Velocity) | 158 |
| 7.8.6 | Injection Pressure | 159 |
| 7.8.7 | Pack Pressure | 159 |
| 7.8.8 | Pack Time | 159 |
| 7.8.9 | Hold Pressure | 160 |

| | | |
|----------|--|------------|
| 7.8.10 | Hold Time | 160 |
| 7.8.11 | Screw Rotation Speed | 160 |
| 7.8.12 | Back Pressure | 161 |
| 7.8.13 | Cooling Time | 164 |
| 7.9 | Additional Settings | 165 |
| 7.9.1 | Decompression or Suck Back Position | 165 |
| 7.9.2 | Pack Speed | 166 |
| 7.9.3 | Tonnage | 166 |
| 7.10 | Process Outputs | 166 |
| 7.10.1 | Actual Melt Temperature | 167 |
| 7.10.2 | Actual Mold Temperature | 168 |
| 7.10.3 | Injection (Fill) Time | 170 |
| 7.10.4 | Peak Injection Pressure | 170 |
| 7.10.5 | Pressure at Transfer | 171 |
| 7.10.6 | Cushion Value | 171 |
| 7.10.7 | Screw Rotation Time | 173 |
| 7.10.8 | Cycle Time | 173 |
| 7.10.9 | Injection Only Shot Weight (Including Runners) | 174 |
| 7.10.10 | Full Part(s) Weight | 175 |
| 7.10.11 | Runner Weights | 175 |
| 7.11 | Decoupled Molding SM | 176 |
| 7.12 | References | 177 |
| 8 | Introduction to Process Development | 179 |
| 8.1 | Introduction | 179 |
| 8.2 | Process Development Fundamentals | 179 |
| 8.3 | Premolding Setup | 182 |
| 8.3.1 | Storage and Drying of Resin | 182 |
| 8.3.2 | Plastic Drying | 182 |
| 8.3.3 | Machine Selection | 185 |
| 8.4 | Importance of Adding Charge Delay Time | 185 |
| 8.5 | Filling in Injection: Weight or Volume? | 187 |

| | | |
|-----------|--|------------|
| 9 | Process Development Part 1: The Melt Preparation | 189 |
| 9.1 | Setting of the Barrel Temperatures | 191 |
| 9.2 | Optimization of Screw Rotation Speeds | 195 |
| 9.3 | Screw Rotation Speed Rule of Thumb That Should Not Be Used | 199 |
| 9.4 | Optimization of Back Pressure | 200 |
| 10 | Process Development Part 2: The 6-Step Study – Exploring the Cosmetic Process | 205 |
| 10.1 | The 6-Step Study | 205 |
| 10.1.1 | Step 1: Optimization of the Injection Phase – Rheology Study | 205 |
| 10.1.1.1 | Procedure to Determine the Viscosity Curve at the Molding Machine | 210 |
| 10.1.1.2 | Interpreting the Data | 212 |
| 10.1.1.3 | Cautions and Exceptions | 213 |
| 10.1.1.4 | Profiling of Injection Speeds | 214 |
| 10.1.1.5 | When a Short Shot Sticks | 215 |
| 10.1.1.6 | Selecting Melt Temperature for Viscosity Graphs | 217 |
| 10.1.2 | Setting the Shot Size and the Transfer Position | 217 |
| 10.1.3 | Step 2: Determining the Cavity Balance – Cavity Balance Study | 219 |
| 10.1.3.1 | Procedure to Determine the Cavity Balance | 221 |
| 10.1.3.2 | Reasons for Cavity Imbalance | 222 |
| 10.1.3.3 | Determining the Cause of Cavity Imbalances | 225 |
| 10.1.3.4 | Calculating Cavity Imbalance | 226 |
| 10.1.3.5 | Acceptable Level of Cavity Imbalance | 227 |
| 10.1.4 | Step 3: Determining the Pressure Drop – Pressure Drop Studies | 229 |
| 10.1.4.1 | Procedure to Determine Pressure Drop | 231 |
| 10.1.4.2 | How to Use the Information from the Study | 235 |
| 10.1.4.3 | Effect of Pressure Drop on the Pack and Hold Phase | 236 |
| 10.1.5 | Step 4: Determining the Cosmetic Process Window – Process Window Study | 237 |
| 10.1.5.1 | Procedure for Determining the Process Window for Amorphous Materials | 241 |
| 10.1.5.2 | Procedure for Determining the Process Window for Crystalline Materials | 242 |
| 10.1.5.3 | How to Use This Information | 243 |

| | | |
|-----------|---|------------|
| 10.1.5.4 | Shape of the Process Window | 244 |
| 10.1.5.5 | Cautions and Exceptions | 245 |
| 10.1.5.6 | Relationship between Cavity Balance and Process Windows | 245 |
| 10.1.5.7 | The Pack and Hold Pressure Rule Not to Be Used | 246 |
| 10.1.6 | Step 5: Determining the Gate Seal Time – Gate Seal Study | 246 |
| 10.1.6.1 | How to Use This Information | 249 |
| 10.1.6.2 | Cautions and Exceptions | 249 |
| 10.1.7 | Differentiating between the Pack and the Hold Phase | 249 |
| 10.1.7.1 | Hot Runner and Valve Gated Molds | 253 |
| 10.1.8 | Step 6: Determining the Cooling Time – Cooling Time Study | 253 |
| 10.1.8.1 | Procedure to Determine Cooling Time | 255 |
| 10.2 | Optimization of Tonnage | 257 |
| 10.3 | The Cosmetic Scientific Process | 260 |
| 10.4 | Post-Mold Shrinkage Studies | 261 |
| 10.4.1 | Procedure to Measure Shrinkage | 263 |
| 10.4.2 | How to Use This Information | 264 |
| 10.5 | Completion of Part 2 of the Recommended Process Development Procedure | 264 |
| 10.6 | Recommended Adjustments to Maintain Process Consistency and Robustness | 266 |
| 10.7 | Process Documentation | 267 |
| 10.8 | References | 267 |
| 11 | Process Development Part 3: Exploring the Dimensional Process via Design of Experiments..... | 269 |
| 11.1 | Why Perform DOEs? | 271 |
| 11.2 | The PVT Diagram and Injection Molding Relationship | 271 |
| 11.2.1 | Design of Experiments: Definition | 272 |
| 11.3 | Terminology | 274 |
| 11.3.1 | Factor | 274 |
| 11.3.2 | Response | 275 |
| 11.3.3 | Level | 275 |
| 11.3.4 | Designed Experiment | 276 |
| 11.4 | Relationships between the Number of Factors, Levels, and Experiments | 277 |

| | | |
|-----------|--|------------|
| 11.5 | Balanced Arrays | 278 |
| 11.6 | Interactions | 280 |
| 11.7 | Confounding or Aliasing | 282 |
| 11.8 | Factorial Experiments | 284 |
| 11.9 | Data Analysis | 285 |
| 11.9.1 | Tornado Charts | 286 |
| 11.9.2 | Contour Plots | 288 |
| 11.9.3 | Prediction Equation | 289 |
| 11.9.4 | Process Sensitivity and Outliers Charts | 289 |
| 11.10 | Using the Results from DOE | 291 |
| 11.10.1 | Process Selection | 291 |
| 11.10.2 | Cavity Steel Adjustment | 291 |
| 11.10.3 | Process Adjustment Tool | 292 |
| 11.10.4 | Setting Process Change Tolerances | 292 |
| 11.10.5 | Reducing Inspection | 293 |
| 11.11 | The Dimensional Process Window (DPW) | 293 |
| 11.12 | Selection of Factors for DOEs | 295 |
| 11.13 | Analysis of Variance (ANOVA) | 299 |
| 11.14 | Collecting Shots for a Quality Check | 301 |
| 11.15 | Choosing the Highs and Lows for DOEs from the Process Window | 302 |
| 11.16 | Randomization | 302 |
| 11.17 | DOE Application to Optimize Pack and Hold Times | 303 |
| 11.18 | Setting Acceptable Machine Tolerances and Alarms during Production .. | 308 |
| 11.19 | Summary | 310 |
| 12 | Mold Qualification Flowchart, Production Release, and Troubleshooting | 311 |
| 12.1 | Process Development Flowchart | 311 |
| 12.1.1 | Stage 1: Development of the Cosmetic Process | 312 |
| 12.1.2 | Stage 2: Mold and Part Quality Qualification Procedure | 313 |
| 12.2 | Mold Qualification Checklist | 313 |
| 12.3 | Process Documentation | 314 |
| 12.3.1 | Process Sheet | 314 |
| 12.3.2 | Waterline Diagrams | 315 |
| 12.3.3 | Mold Temperature Maps | 316 |

| | | |
|-----------|--|------------|
| 12.3.4 | Setup Instructions | 317 |
| 12.3.5 | Operator Instructions | 317 |
| 12.4 | Documentation Books | 318 |
| 12.5 | Qualification Production Runs | 319 |
| 12.6 | Mold Specific Troubleshooting Guide | 319 |
| 12.7 | Molding Startup and Shutdown | 320 |
| 12.7.1 | Purging | 320 |
| 12.7.2 | Startup of a Molding Machine | 321 |
| 12.7.3 | Shutdown of a Molding Machine | 322 |
| 12.8 | Troubleshooting | 322 |
| 12.9 | Important Equipment and Tools for Qualifications and Troubleshooting | 325 |
| 12.10 | Common Defects, Their Causes, and Prevention | 326 |
| 12.10.1 | Splay: What Is It? How to Get Rid of It? | 327 |
| 12.10.2 | Defects in Molding | 329 |
| 13 | Role of Mold Cooling, Venting, and Regrind in Process Development | 335 |
| 13.1 | Mold Cooling | 335 |
| 13.1.1 | Number of Cooling Channels | 336 |
| 13.1.2 | Reynolds Number of the Coolant Flow | 336 |
| 13.1.3 | Type of Coolant | 337 |
| 13.1.4 | Series and Parallel Cooling | 338 |
| 13.2 | Venting | 339 |
| 13.2.1 | Dimensions of the Vent | 340 |
| 13.2.2 | Primary Vent Depths | 341 |
| 13.2.3 | Location of Vents | 344 |
| 13.2.4 | Forced Venting or Vacuum Venting | 345 |
| 13.3 | Regrind | 346 |
| 13.3.1 | Effect of the Molding Process on the Part Properties | 347 |
| 13.3.2 | Using Regrind | 348 |
| 13.3.3 | Batch and Continuous Processes of Incorporating Regrind | 349 |
| 13.3.4 | Estimating the Amount of Regrind from Different Generations ... | 350 |
| 13.3.5 | Effect of Regrind on Processing | 352 |
| 13.3.6 | Closing Remarks | 353 |

| | | |
|-------------------|---|------------|
| 14 | Related Technologies and Topics | 355 |
| 14.1 | Cavity Pressure Sensing Technology | 355 |
| 14.1.1 | Sensors and Output Graphs | 356 |
| 14.1.2 | Types and Classification of Pressure Sensors | 357 |
| 14.1.3 | Use of Information from the Pressure Graphs | 359 |
| 14.1.4 | Controlling the Process with Cavity Pressure Sensors | 361 |
| 14.1.5 | Sensor Locations | 363 |
| 14.2 | Building a Knowledge Base | 364 |
| 14.3 | Concurrent Engineering in Injection Molding | 366 |
| 14.3.1 | The Product Designer | 368 |
| 14.3.2 | The Tooling Engineer | 369 |
| 14.3.3 | The Mold Designer and Mold Maker | 369 |
| 14.3.4 | The Material Supplier | 370 |
| 14.3.5 | The Process Engineer | 370 |
| 14.3.6 | The Quality Engineer | 371 |
| 14.3.7 | The Sales Team at the Molder | 371 |
| 14.3.8 | Mandatory for All Departments | 372 |
| 14.3.9 | Implementing Concurrent Engineering | 372 |
| 15 | Quality Concepts | 375 |
| 15.1 | Basic Concepts | 375 |
| 15.2 | Histogram | 376 |
| 15.3 | Normal Distribution | 377 |
| 15.4 | Standard Deviation | 378 |
| 15.5 | Specification Limits and Standard Deviation | 379 |
| 15.6 | Capability Index | 380 |
| 15.7 | Process Capability | 382 |
| 15.8 | Statistical Quality Control (SQC) and Statistical Process Control (SPC) | 383 |
| 15.9 | References | 384 |
| Appendix A | Materials Data Sheet | 385 |
| Appendix B | Conversion Tables for Commonly Used Process Parameters | 391 |
| Appendix C | Water Flow Tables | 393 |

| | | |
|-------------------|---|------------|
| Appendix D | Part Design Checklist | 395 |
| Appendix E | Mold Design Checklist. | 397 |
| Appendix F | Mold Qualification Checklist. | 399 |
| Appendix G | Regrind Tables – Percentage of Regrind in Total Shot | 401 |
| Appendix H | Calculation of Melt Density | 405 |
| Index | | 407 |